

# SUPERB

## Quick Guide

Front View



SD Card

Keypad

Select a function. Control the function with the Up/Down arrows

